



TYPICAL CROSS SECTION
FOR SPADE EDGE

NOTES

1. SPRAY ALL WEEDS AND UNWANTED PLANT MATERIAL WITH A SUITABLE HERBICIDE TWO WEEKS PRIOR TO WORKS. REPEAT SPRAY MAY BE NECESSARY.
2. CULTIVATE WITH MECHANICAL ROTARY HOE TO A DEPTH OF 200MM UNLESS AROUND TREE ROOTS THEN HAND CULTIVATION RESERVED.
3. REMOVE ALL RUBBISH AND DELETERIOUS MATERIALS.

CITY OF CASEY

SOFT LANDSCAPING
SPADE EDGE DETAIL

MANAGER OF ENGINEERING &
ENVIRONMENTAL SERVICES
LAST UPDATE 09.11.2012

AMENDMENTS:

S-1009